

### Intelligent LED Driver (Constant Voltage)

- The housing is made from V0 flame retardant PC materials from SAMSUNG/COVESTRO.
- The clamshell design and screwless type for strain-relief, The design of dismountable end cap allows you to adjust the length of housing depending on your needs.
- Change the dimming method, PWM frequency and other parameters via the APP.
- Bluetooth 5.0 SIG Mesh with high networking capability are reliable and stable.
- Support control iOS or Android devices through Bluetooth connection.
- With soft-on and fade-in dimming function, enhancing your
- The whole dimming process is flicker-free with high frequency exemption level.
- Dimming from 0-100%, down to 0.0001%
- Comply with the EU's ErP Directive, networked standby<0.5W.
- Overheat, over voltage, overload, short circuit protection and
- Suitable for ClassI/II/III indoor light fixtures.
- Normal service life can reach 100,000 hours.
- 5-year warranty (Rubycon capacitor).



LM-240-24-G1B









## **Technical Specs**


Model		LM-24	)-24-G1B				
	Output Type		nt voltage				
Features	Dimming Interface		oth 5.0 SIG Mesh				
	Output Feature	Isolatio					
	Protection Grade	IP20					
	Insulation Grade		Class II (Suitable for class I/ II / III light fixtures)				
	Output Voltage	24Vdc	(outlable for class i, ii	, in agric (include)			
OUTPUT	Output Voltage Range	24Vdc±0.5Vdc					
	Output Current	Max. 10					
	Output Power	Max. 24					
	Dimming Range	0~100%, down to 0.0001%					
	Ripple(maximum)	200mVp-p					
	Voltage Accuracy	±5%					
	PWM Frequency	≤22000Hz (NFC setting range 300-22000Hz)					
	DC Voltage Range	200-250Vdc					
	AC Voltage Range	220-240Vac					
	EoFv	EoFv=99.6%					
	Input Voltage	20-240Vac					
	Frequency	22U-24UVac 50/60Hz					
	Input Current						
INPUT	Power Factor	Max. 1.18A/230Vac PF>0.99/230Vac, at full load					
INPUT	THD						
	Efficiency (Typ.)	THD <s5%@230vac, at="" full="" load<="" td=""></s5%@230vac,>					
	Inrush Current						
	Anti Surge	Cold start 55A(Test twidth=1200us tested under 50%   Ipeak)/230Vac L-N: 2KV					
	Leakage Current		Max. 0.5mA				
	Working Temperature		~ 45°C tc: 86°C				
	Working Humidity		%RH, non-condensing				
ENVIRONMENT	Storage Temperature/Humidity	20 ~ 95%RH, non-condensing					
ENVIRONMENT	Temperature Coefficient	±0.03%/°C(0-50°C)					
	Vibration						
	Overload Protection	10~500Hz, 2G 12min/1cycle, 72 min for X, Y and Z axes respectively					
	Overheat Protection	Shut down the output when rated power≥110%, auto recovers  Intelligently adjust or turn off the output current if the PCB temperature ≥110°C, and recover automatically					
PROTECTION	Overvoltage Protection	Shut down the output when voltage>28V, and recover automatically					
	Short Circuit Protection	Enter hiccup mode if short circuit occurs, and recover automatically					
	Withstand Voltage		I/P-0/P: 3750Vac				
	Insulation Resistance		P: 100MΩ/500VDC/25	°C /7∩0/, DU			
	Ilisulation Resistance	CCC	China	GB19510.1, GB19510.14			
	Safety Standards	TUV	Germany	EN61347-1, EN61347-2-13, EN62493			
		CB	CB Member States	IEC61347-1, IEC61347-2-13			
		CE	European Union	EN61347-1, IEC61347-2-13 EN61347-1, EN61347-2-13, EN62384			
		KC		KC61347-1, KC61347-2-13			
		EAC	Korea Russia	IEC61347-1, IEC61347-2-13			
SAFETY		RCM	Australia	AS 61347-1, AS 61347-2-13			
&		ENEC		· ·			
EMC		UKCA	Europe	EN61347-1, EN61347-2-13, EN62384 BS EN 61347-1, BS EN 61347-2-13, BS EN 62493			
			Britain				
	EMC Emission	CCC	China	GB/T17743, GB17625.1			
		CE	European Union	EN55015, EN61000-3-2, EN61000-3-3, EN61547			
		KC	Korea	KSC 9815, KSC 9547			
		EAC	Russia	IEC62493, IEC61547, EH55015			
		RCM	Australia	EN55015, EN61000-3-2, EN61000-3-3, EN61547			
	EMO!	UKCA		BS EN IEC 55015, BS EN IEC 61000-3-2, BS EN 61000-3-3, BS EN 61547			
	EMC Immunity	EN61000-4-2,3,4,5,6,8,11, E					
	Power Consumption	Networked standby		<0.5W (After shutdown by command)			
		No-load power consumption		<0.5W (When the lamp is not connected)			
ErP	Flicker/Stroboscopic Effect	IEEE 1789		Meet IEEE 1789 standard/High frequency exemption level			
		CIE SVM		Pst LM<1.0, SVM<0.4			
	DF	Phase factor		DF≥0.9			
OTUEDO	Weight(N.W.)	555g±10g					
OTHERS	Dimensions		7.5×30mm(L×W×H)				

The driver is suitable for connecting resistor current-limiting LED fixture (e.g., LED strip). The inrush current will be dozens of times increased if connecting built-in constant current IC current-limiting LED fixtures, the driver will activate the overloaded protection (hiccups flickering). When you order, please remark controlling the constant current LED fixture (e.g. MR16 lamp, underground light, LED wall washer, constant current LED strip, etc.), so that we can prepare them with special procedures.




### **Product Size**

Unit: mm



# Wiring Diagram



# Protective Housing Application Diagram















Open the protective housing and push the side housing outwards to pry up the wire fixing board with a screwdriver . Then connect to electrical wires as wiring diagram shows. Press down the wire fixing board to fix the the electrical wires, finally close the protective housing.

Press down the back side of the protective housing and move it from side to side to





### Installation Precautions






Please do not stack the products. The distance between two products should be  $\geqslant$ 15cm so as not to affect heat dissipation and the lifespan of the products.






Please do not place the products on the floor. The distance between the product and the floor should be  $>100\,\mathrm{cm}$  so as to avoid signal interference.

LM-240-24-G1B





Please do not place the products near a large area of metal objects (such as metal stud ceilings). The distance between the product and the metal object should be >15cm so as to avoid signal interference.





Please do not install the products on beams or near the corners. The distance between the product and the beam or the corner should be  $\geqslant 15 \mathrm{cm}$  so as to avoid signal interference.

## Use the NFC Lighting APP

Scan the QR code below with your mobile phone and follow the prompts to complete the APP installation (According to performance requirements, you need to use a NFC-capable Android phone, or an iphone 8 and later that are compatible with iOS 13 or higher).




\* Before you begin setting the parameters of the driver, please make sure the driver is powered off.

### Read/Write the LED driver

Use your NFC-capable phone to read LED driver data, then edit the parameters and they can be directly written to the driver.

### 1. Read the LED driver

On the APP home page, click [Read/Write LED driver], then keep the programmer's sensing area close to the NFC logo of the driver to read the driver parameters.



### 2. Edit the parameters


Click [Parameter settings] to edit the advanced parameters, like output current, like output current, time for fading on/off, power-on status, PWM Frequency etc.

### 3. Write to the driver

After completing the parameter settings, click [Write] in the upper right corner, and keep the programmer's sensing area close to the NFC logo of the driver, so the parameters can be written to the driver.















### **Recommend Applications**

1. Achieve fast dimming control.



2. Both App and remote can control the driver after connecting the remote to the driver with App.



3. Both App and Super Panel 6S can control the driver simultaneously after connecting the Super Panel 6S to the driver with App. By connecting the Super Panel to network, you are allowed to control the driver, cloud scenes and automation remotely with App.



4. .....More applications of intelligent control are waiting for you to set up.

LM-240-24-G1B



### Use with Bluetooth L-Home APP

#### 1. Register an account


The App is available on iOS or Android devices. Scan the QR code below with you mobile phone and follow the prompts to complete the App installation. Open the App to log in or register an account.



#### 2. Paring instructions

Open the APP and create a home if you are a new user. Click "+" icon in the upper right corner and access the "Add Device" list, then follow the prompts to add the device. Pick "Smart lighting-DIM light" from the list and follow the prompts to power on the device firstly. Make sure the device is not connected to the network. Then click "Bluetooth Search" and follow the prompts to add the device.








### 3. Control interface settings

After pairing up your device, go to the control interface. You'll be able to achieve your desired lighting effects by changing brightness and color temperature. Click "Theme" and you'll easily switch to multiple theme lighting effects with one tap. Click "Mode" and the App provides you editable advanced modes. Customize dynamic modes to put you into a more colorful life.









#### 4. Light groups

Users are able to combine the same type of light fixtures into a group to control them simultaneously. Once you create the group, you can set the dim level more easily. Pick "Group-DIM light group" from the list. Follow the prompts to rename the group and click "Next" to pick the lights you are going to group together and click "Save".









LM-240-24-G1B

#### 5. Advanced functions

This driver can be linked up with gateway function devices (such as Super Panel 6S) to achieve the advanced functions from local scenes and cloud scenes to automation.








### Reset The Device (Reset to factory defaults)

Make sure the driver is well-connected to a lamp and the lamp is on, turn it off with the switch and after 15s turn it on. After 2s, turn it off again. Repeat the same operation 6 times. When the lamp flashes 5 times, reset the device to factory defaults successfully.





Under the driver being power-on


Turn it off — 15s — 2s — ...... (Repeat 6 times)




### Relationship Diagrams











# Flicker Test Form








# Packaging Specifications

Model	LM-240-24-G1B
Carton Dimensions	400×350×120mm(L×W×H)
Quantity	10 PCS/Layer; 2 Layers/Carton; 20 PCS/Carton
Weight	0.555 kg/PC; 12 kg±5%/Carton

# Packaging Image







Carton Packaging

### Transportation and Storage

### 1. Transportation

Products can be shipped via vehicles, boats and planes.

During transportation, products should be protected from rain and sun. Please avoid severe shock and vibration during the loading and unloading process.

2. Storage

The storage conditions should comply with the Class I Environmental Standards. The products that have been stored for more than six months are recommended to be re-inspected and can be used only after they have been qualified.

LM-240-24-G1B



### **Attentions**

- Products shall be installed by qualified professionals.
- LTECH products are and not lightning proof non-water proof (special models excepted). Please avoid the sun and rain. When installed outdoors, please ensure they are mounted in a water proof enclosure or in an area equipped with lightning protection devices.
- Good heat dissipation will prolong the working life of products. Please ensure good ventilation.
- Please check if the working voltage used complies with the parameter requirements of products.
- $\bullet \ \ \, \text{The diameter of wire used must be able to load the light fixtures you connect and ensure the firm wiring.}$
- Before you power on products, please make sure all the wiring is correct in case of incorrect connection that causes damage to light fixtures.
- If a fault occurs, please do not attempt to fix products by yourself. If you have any question, please contact your suppliers.
- \* This manual is subject to changes without further notice. Product functions depend on the goods. Please feel free to contact our official distributors if you have any question.

### Warranty Agreement

- Warranty periods from the date of delivery: 5 years.
- Free repair or replacement services for quality problems are provided within warranty periods.

#### Warranty exclusions below:

- Beyond warranty periods.
- Any artificial damage caused by high voltage, overload, or improper operations.
- Products with severe physical damage.
- Damage caused by natural disasters and force majeure.
- · Warranty labels and barcodes have been damaged.
- No any contract signed by LTECH.
- 1. Repair or replacement provided is the only remedy for customers. LTECH is not liable for any incidental or consequential damage unless it is within the law.
- $2.\ \mathsf{LTECH}\ \mathsf{has}\ \mathsf{the}\ \mathsf{right}\ \mathsf{to}\ \mathsf{amend}\ \mathsf{or}\ \mathsf{adjust}\ \mathsf{the}\ \mathsf{terms}\ \mathsf{of}\ \mathsf{this}\ \mathsf{warranty},\ \mathsf{and}\ \mathsf{release}\ \mathsf{in}\ \mathsf{written}\ \mathsf{form}\ \mathsf{shall}\ \mathsf{prevail}.$

ZHUHAI LTECH TECHNOLOGY CO., LTD.

LM-240-24-G1B



# **Update Log**

Version	Updated Time	Update Content	Updated by
Α0	2024.01.18	Original version	Li Siyu